




## technics




Lamptype	Reference	Max. watt	Voltage	Freq.	B	H	A
Mini rokko QT9-ax	KR94301x	14W	12V		90	140	100
Mini rokko QT9-ax gear incl	KR94311x	14W	230V/12V	50/60Hz	90	140	100
Mini rokko LED	KR94302x	1,2W			90	140	100
Mini rokko LED gear incl	KR94312x	1,2W	230V	50/60Hz	90	140	100
Mini square rokko QT9-ax gear incl	KR94331x	35W	230V/12V	50/60Hz	140	140	106
Mini square rokko LED gear incl	KR94332x	3x1,2W	230V	50/60Hz	140	140	106
Mini square rokko TC-L gear incl	KR94334x	5W	230V	50	140	140	106

## 1 dimensions




	W	L	D	X	Y	Z
Mini rokko KR94301x, KR94311x, KR94302x, KR94312x	75	125	80	80	125	80
Mini sq rokko KR94331x, KR94332x, KR94334x	125	125	85	125	125	85




## 2 cut out

In case of concrete wall use concrete pouring mould KR743004 (Mini rokko) or KR743304 (Mini Sq rokko).




## 3 installation

Insert cable.




If two grommets are necessary remove the knock-out.



Make connection.




In case of LED.

Wiring diagram: series circuit LED



## 4 installation

## technics






## 5 installation

In case of TC-L, insert lamp before fixing the screening cap on the base.

Put the gear in the base and fix the screening cap on the base with one screw.

Place the luminaire in the wall.






## 6 installation

Fasten the two screws.

In case of plasterboard use installation set KR743002 (manual kr8430021653).

In case of Qt9-ax insert lamp.

In case of Qt12-ax insert lamp.




## 7 installation

Add cover.

Attach cover to the hinge and rotate while closing.

For the Mini Rokko fix the cover with the enclosed screw. Do not use alternative screw otherwise IP65 is not guaranteed.



## 8 pictures

For the Mini Square Rokko fix the cover with an allen key

