


# kreon installation manual


## technics & dimensions




name	reference	voltage VAC	frequency	led current	nom. current driver	max. power	power factor	LxWxH
esprit double floor	KR96311X-XXXX-SP	220-230V	50/60Hz	700mA	xxA	32W	0,97%	LxWxH
	KR96311X-XXXX-(W)DL	220-230V	50/60Hz	700mA	xxA	32W	0,97%	LxWxH

## 1. installation

The light source contained in this luminaire shall only be replaced by the manufacturer or his service agent or a similar qualified person.



The gear contained in this luminaire shall only be replaced by the manufacturer or his service agent or a similar qualified person.



Please make sure the main voltage is disconnected before proceeding!




This product contains a light source of Energy Efficiency Class:


reference	Energy Efficiency Class
KR96311X-XXXX-SP	TBD
KR96311X-XXXX-(W)DL	TBD

## 2. installation


To install the base.  
See installation manual KR8630002094



Remove the endbushing




Guide the connector with cables through the hole and mount the tube in the base




# kreon installation manual

## 3. installation

Guide the red and black cable with connector through the end bushing and screw the end bushing to the tube.




Make connection to the driver with the connector




## 4. installation


Lock the tube by screwing the set screw



Guide the power supply through the hole in the baseplate. Close the base with 4 screws



Aim the fixtures, 360° rotation and 90° inclination and connect the power supply



## 5. installation

Optional: Secure the heads with allen key



## 6. pictures

