


kreon installation manual


technics & dimensions




name	reference	current	current directional
Inti 80 fixed	KR99711X-XXXX-XX	350mA	
Inti 80 fixed dtw	KR99761X-XX	350mA	
Inti 80 directional	KR99712X-XXXX-XX-XX	350mA	350mA
Inti 80 directional dtw	KR99762X-XXXX-XX-XX	350mA	350mA

Please make sure the main voltage is disconnected before proceeding! ⚡


1. installation



To install the plasterkit, see installation manual KR8170001755




To install the installation ring, see installation manual KR8166002147




Install the plastic ring in the plasterkit.


2. installation



Connect driver




Put the assembly in the plasterkit/trim.




push the fixture in the plasterkit

kreon installation manual

3. installation



click assembly in the ring of the plasterkit



In case of directional,
inclination of 30° is possible


Push the tube manually

electric connection

In case of dim to warm (DTW): driver with AM or
hybride (AM+PWM) dimming needed


In case of Inti directional, always use two driver to have two separate circuits.
Except when using dual-drive DALI type 6 (DT6) it is possible
to use one driver to control two circuits.
Never use DALI type 8 (DT8)

The light source contained in
this luminaire shall only be
replaced by the manufacturer
or his service agent or a similar
qualified person.




Electrical scheme


LED = 1



LED > 1




directional



To remove the Inti directional out of the ceiling,
just pull at the directional tube.

fixed



To remove the Inti fixed out of the ceiling,
see manual KR8000002355