




















technics		  				Name	Reference	LxHxW	ZxYxDmin												
1 dimensions						Rei 165	KR783010	239x249x53	180x190x55												
						Rei 300	KR783020	374x249x53	315x190x55												
2 installation		 	 	 	Use bottom hole to guide the power cable when fixture is used as a downlight				Use upper hole to guide the power cable when fixture is used as an uplight												
					Place the plasterkit in the hole.				Fix the plasterkit with plasterboard screws.				Fill around perimeter of plasterkit using suitable filler and plaster to hide screws and plasterkit.								
3 installation		 	 	 																	
4 installation	kreon nv			 	Minimum filler distance, spread out until zero.				Unscrew the fixing screws and install the fixture, see manual KR8832101825.												
					Industrieweg Noord 1152 3660 Opglabbeek Belgium				Tel + 32 89 81 97 80 Fax + 32 89 81 97 90				www.kreon.com mailbox@kreon.be								
																		revision date: 16/05/12			
																		KR8832201827			
																		Sheet 1/1			