


kreon installation manual

technics & dimensions



name	reference	A	B	C	D	Board thickness
Lini 10 plasterkit	KR774210	26	15.5	48	90	12.5/15/18 or 2x12.5mm




Please make sure the main voltage is disconnected before proceeding! ⚡

1. installation

In case of plasterboards 12.5, 15 or 18mm

Provide a 50mm wide cut out


Provide 24V cables
Place power supply on remote




The plasterkit can be mounted to 3 plasterboard thicknesses depending on the level and holes used to screw the mounting brackets

	Level	Hole
Thickness 12.5	2	A
Thickness 15	2	B
Thickness 18	1	C

2. installation



Install mounting brackets to the plasterkit, use 4 brackets per meter




In case of a plasterkit built out of multiple pieces connect the pieces using 2 cross connectors. They slide in sideways and can be fastened with 4 set screws.

The same system is used to connect corners, please check manual KR8000002309


kreon installation manual

3. installation





4. installation

In case of 2 layers of plasterboard 12.5mm



accessories



Included with the plasterkit there is a remover tool. By clamping it's flanges under the edges of an installed Lini 10 profile, the profile can be pulled out of the plasterkit.