


kreon installation manual

technics & dimensions




name	reference	drawing
mounting bracket for cavity ceilings	KR726056	A
recessed profile	KR726055	B
snap hangers for recessed profile	KR726057	C

Please make sure the main voltage is disconnected before proceeding! ⚡


1. cut profile

saw the profile to the desired length



2. installation in cavity ceilings (solid or wooden ceilings)

the height of the bracket can be adjusted to the thickness of the ceiling to ensure a flush mount






name	reference
recessed profile	KR726055
mounting bracket for cavity ceilings	KR726056

kreon installation manual

3. installation in drywall ceiling




suspend the profile using the profile snap hangers and quick adjust hangers



name	reference
recessed profile	KR726055
snap hangers for recessed profile	KR726057

4. installation in wet plaster ceiling

there is no specific correct way to install the support profile
the installation procedure depend on the condition on the building site
and your own particular desires





name	reference
no accessories available	

5. installation of the 230V track

end feed

mid feed




name	reference
end feed left, white	KR726511
end feed left, black	KR726512
end feed right, white	KR726521
end feed right, black	KR726522
mid feed, white	KR726531
mid feed, black	KR726532
end feed left, databus, white	KR736511
end feed left, databus, black	KR736512
end feed right, databus, white	KR736521
end feed right, databus, black	KR736522


kreon installation manual

installation of 230V track

end feed, cable entry from top




end feed, cable entry from side




installation of 230V track

drive the screws into the toggle nuts,
3 revolutions only



make sure the toggle nuts are
installed right side up as shown



first turn all screws 90° clockwise until track is flush in the recessed profile
starting from the middle and working outwards
then go back and tighten all the screws firmly

