










	Nuit recessed profile	<div><div>Name</div><div>Nuit recessed profile</div></div> <div><div>Reference</div><div>kr703055</div></div> <div><div>L x W x H</div><div>L x 50mm x 88mm L x 2 1/8" x 3 1/2"</div></div>
	<div></div>	<div><div>Attention:</div><div><div>- make sure there is one connection per section of Nuit profile</div><div>- in case of the use of an emergency kit, make sure the emergency is on a separate circuit and having permanently voltage</div></div><div>Please make sure that mains voltage is disconnected before installing! ⚡</div></div>
1	dimensions	
2	installation for solid ceiling	<div><div><div></div><div>fix the mounting brackets kr703056 on the recessed profile; adjust the height of the bracket according to the thickness of the ceiling to ensure a trimless mount</div></div><div><div></div><div>attach the recessed profile to hangers</div></div><div><div></div><div>install the ceiling for installation of Nuit profile; see item 5</div></div></div>
3	installation for dry plaster ceiling	<div><div><div></div><div>suspend the profile using the profile snap hangers kr726057 and quick adjust hangers</div></div><div><div></div><div>install the plasterboard for installation of Nuit profile; see item 6</div></div></div>
	kreon nv	


Installation of Nuit recessed




no specifically correct way to install the support profile;
the installation procedure depends on the conditions on the
building site and your own particular desires

for installation of Nuit profile; see item 5


4 installation for
wet plaster ceiling



make cut-out in plasterboard
according to the dimensions of the installation profile




plasterboard thickness: 9.5 - 22mm




supply correct power
(see table of on the next page)
ATTENTION: switch power off while installing!


5 installation in
solid plaster
ceiling



place U-shaped brackets on the ceiling
appr. 60mm from the center of bracket
to the end of the gap





fix the brackets with screws on plasterboard



pull wire through center hole of the profile
and fix the profile to the brackets


Installation of Nuit recessed



6 installation of Nuit

use the supplied parallelogram shaped nuts
and screws with countersunk heads

set the nut on top of the screw



make correct connection with male
connector in luminaire

fix the luminaire in the installed recessed profile