


technics



Plasterboard installation set


Reference

KR743002

Min plasterboard thickness


10

1 dimensions




Add the brackets to the housing.

Align the holes of the bracket with the protrusions of the base.



Do not use automatic screwdriver
Tightening moment = Max 0,8Nm.

2 installation



3 installation

Put the luminaire through the hole.

4 installation

kreon nv

Industrieweg Noord 1152
3660 Opglabbeek
Belgium

Tel + 32 89 81 97 80
Fax + 32 89 81 97 90

www.kreon.com
mailbox@kreon.be

revision date: 09/06/09
KR8430021653