








technics	<div><div>In case of precast concrete panels, gear inclusive.</div><div></div></div> <div><div>In case of finished concrete ceiling, gear exclusive.</div><div></div></div>	<table><tr><th>Name</th><th>Reference</th><th>Lamptype</th><th>Ø A</th><th>E</th><th>F</th><th>G</th><th>B</th><th>D</th></tr><tr><td>Concrete plasterkit down IL 120 (shadow gap)</td><td>KR707219</td><td>LED directional</td><td>Ø 140</td><td>305</td><td>305</td><td>200</td><td>Ø or □ 305</td><td>200</td></tr><tr><td></td><td>KR707211</td><td>LED directional</td><td>Ø 140</td><td>305</td><td>305</td><td>200</td><td>Ø or □ 305</td><td>200</td></tr><tr><td>Concrete plasterkit down IL 120 (shadow gap)</td><td>KR707219</td><td>LED dir low</td><td>Ø 140</td><td>305</td><td>305</td><td>200</td><td>Ø or □ 305</td><td>200</td></tr><tr><td></td><td>KR707211</td><td>LED dir low</td><td>Ø 140</td><td>400</td><td>400</td><td>140</td><td>Ø or □ 305</td><td>237</td></tr></table>	Name	Reference	Lamptype	Ø A	E	F	G	B	D	Concrete plasterkit down IL 120 (shadow gap)	KR707219	LED directional	Ø 140	305	305	200	Ø or □ 305	200		KR707211	LED directional	Ø 140	305	305	200	Ø or □ 305	200	Concrete plasterkit down IL 120 (shadow gap)	KR707219	LED dir low	Ø 140	305	305	200	Ø or □ 305	200		KR707211	LED dir low	Ø 140	400	400	140	Ø or □ 305	237
Name	Reference	Lamptype	Ø A	E	F	G	B	D																																							
Concrete plasterkit down IL 120 (shadow gap)	KR707219	LED directional	Ø 140	305	305	200	Ø or □ 305	200																																							
	KR707211	LED directional	Ø 140	305	305	200	Ø or □ 305	200																																							
Concrete plasterkit down IL 120 (shadow gap)	KR707219	LED dir low	Ø 140	305	305	200	Ø or □ 305	200																																							
	KR707211	LED dir low	Ø 140	400	400	140	Ø or □ 305	237																																							
1 cut out																																															
2 dimensions	<div></div>																																														
3 installation	<div><p>Put the plasterkit through the hole.</p></div>	<div><p>Fix the plasterkit with screws.</p></div>	<div><p>Fill around perimeter of plasterkit using suitable filler and plaster to hide screws and plasterkit.</p></div>																																												
4 installation	<div><p>Minimum filler distance, spread out until zero.</p></div>																																														
kreon nv	Industrieweg Noord 1152 3660 Opglabbeek Belgium	Tel + 32 89 81 97 80 Fax + 32 89 81 97 90	www.kreon.com mailbox@kreon.be	revision date: 05/01/17 KR8072102028	sheet 1/1																																										