






technics	<p>Installation instructions for Cadre 900 and Cadre 1200 Model numbers: ku963750, ku963752, ku963753, ku963770, ku963772, ku963773</p> <p><b>! WARNING:</b> READ AND UNDERSTAND THESE INSTRUCTIONS BEFORE STARTING INSTALLATION. KEEP THIS DOCUMENT FOR FUTURE REFERENCE.</p>	<p>THIS LUMINAIRE MUST BE INSTALLED TO CONFIRM WITH NEC AND ALL LOCAL ELECTRICAL &amp; BUILDING CODES &amp; PRACTICES. TO ASSURE FULL COMPLIANCE WITH LOCAL CODES AND REGULATIONS, CONSULT WITH YOUR LOCAL ELECTRICAL INSPECTOR BEFORE INSTALLATION.</p>	<ul style="list-style-type: none"> <li>- DISCONNECT POWERSUPPLY BEFORE INSTALLING OR SERVICING</li> <li>- ENSURE THE LUMINAIRE IS GROUNDED</li> <li>- LUMINAIRE IS SURFACE MOUNTED ONLY</li> <li>- SUPPLY CONDUCTORS (POWER WIRES) CONNECTING THE LUMINAIRE MUST BE RATED 90°C.</li> <li>- THIS LUMINAIRE MUST BE MOUNTED OR SUPPORTED INDEPENDENTLY OF AN OUTLET BOX</li> </ul>	<ul style="list-style-type: none"> <li>- REPLACE REMOVABLE PARTS AFTER SERVICING</li> <li>- SUITABLE FOR INDOOR DRY LOCATIONS ONLY</li> </ul>
1 notifications		RISK OF FIRE! - RISK OF SHOCK!	 	
2 installation	<p>can only be installed on standard octagonal conduit box size 4</p>	<p>use plasterkit that fits on the junction-box</p>		
3 installation	<p>1. screw plasterkit on the octagonal junction-box size 4</p>	<p>2. pull wire through hole and finish with plaster</p>	<p>3. drill 4 holes (diam. 1/4") according to the drawing in step 4 and insert plugs</p>	<p>4. drill pattern with the junction-box centered</p>  <p>cadre 900: x = 26 2/5" cadre 1500: x = 50"</p>
4 installation	<p>5. fix brackets</p>	<p>6. remove big bolts of the pendant system and release the others for 3/4 of their length</p>	<p>7. slide bolts of pendants into keyhole slots and fasten all bolts</p>	<p>8. use 4x hexag. screws to secure pendants</p>


## 5 installation




9. slide in keyhole slot to fix against ceiling



10. use set screws (4x) to adjust height





11. connect powersupply and dim-signal, connect 5-pole connectors



12. after connection, replace covers and louvre so all wiring and connections are enclosed

## 6 connection



The luminaire can only be used with Kreon reflectors.

This installation manual might not cover all details or variations. When additional information is required, please contact your local representative, or one of the Kreon offices.

## 7 picture

**kreon nv**

Industrieweg Noord 1152  
B-3660 Opglabbeek  
Belgium

Tel + 32 89 81 97 80  
Fax + 32 89 81 97 90

[www.kreon.com](http://www.kreon.com)  
[mailbox@kreon.be](mailto:mailbox@kreon.be)

Rev. date: 13/11/2008  
KU8637521610