



IMPORTANT SAFETY INSTRUCTIONS - SAVE THESE INSTRUCTIONS

Installation instructions for Prologe 145 in-Line and in-Dolma. Model numbers: ku(x)98511_, ku(x)98512_, ku98513_, ku(x)98521_, ku(x)98522_, ku98518_, ku98519_, ku98528_, ku98525_

 **WARNING:** READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE STARTING INSTALLATION. SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE

 **RISK OF FIRE! - RISK OF SHOCK!**

- INSTRUCTIONS PERTAINING TO A RISK OF FIRE OR INJURY TO PERSONS
THIS LUMINAIRE MUST BE INSTALLED TO CONFIRM WITH NEC AND ALL LOCAL ELECTRICAL & BUILDING CODES & PRACTICES. TO ASSURE

FULL COMPLIANCE WITH LOCAL CODES AND REGULATIONS, CONSULT WITH YOUR LOCAL ELECTRICAL INSPECTOR BEFORE INSTALLATION.

- DISCONNECT POWERSUPPLY BEFORE INSTALLING OR SERVICING
- ENSURE THE LUMINAIRE IS GROUNDED
- LUMINAIRE MAY NOT COME IN CONTACT WITH INSULATION. ANY INSULATION IS A MINIMUM OF 3" AWAY FROM HOUSING.
- NON IC TYPE LUMINAIRE
- BLINKING LIGHT OF THIS THERMALLY PROTECTED LUMINAIRE MAY INDICATE OVERHEATING
- SUITABLE FOR INDOOR DRY LOCATIONS ONLY
- SUITABLE FOR INDOOR DRY LOCA-

TIONS ONLY


- SUPPLY CONDUCTORS (POWER WIRES) CONNECTING THE LUMINAIRE MUST BE RATED 90°C
- CAUTION - TO REDUCE RISK OF FIRE, DO NOT USE LAMP IDENTIFIED FOR USE IN ENCLOSED LUMINAIRES ONLY

WARNING - to reduce the risk of FIRE OR INJURY:

- turn off power and allow to cool before replacing lamp
- lamp gets HOT quickly! contact only switch/plug when turning on
- do not touch hot lens, guard, reflector or enclosure
- keep lamp away from materials that may burn
- do not touch lamp at any time; use soft cloth; oil from skin may damage

the lamp


- do not operate the luminaire with a missing or damaged shield, if required
- This luminaire can only be used with Kreon accessories.

 = CAUTION - RISK OF FIRE - do not install a lamp identified for use only in enclosed luminaires

This installation manual might not cover all details or variations. When additional information is required, please contact your local representative, or one of the Kreon offices.

1 notifications

Notice de montage pour Prologe 145 in-Line and in-Dolma.

 **ATTENTION:** LIRE ET COMPRENDRE TOUTES LES INSTRUCTIONS AVANT L'INSTALLATION CONSERVER CES INSTRUCTIONS POUR DE FUTURES REFERENCES

 **RISQUE D'INCENDIE! RISQUE DE CHOC!**


- INSTRUCTIONS RELATIVES À UN RISQUE D'INCENDIE OU DE BLESSURE
- CE PRODUIT DOIT ETRE INSTALLE SELON LE CODE D'INSTALLATION PERTINENT, PAR UNE PERSONNE QUI CONNAIT BIEN LE PRODUIT ET SON FONCTIONNEMENT AINSI QUE LES RISQUES INHERENTS
- CONSULTER UN ELECTRICIEN QUALIFIE POUR VOUS ASSURER QUE LES CONDUCTEURS DE LA DERIVA-

TION SONT ADEQUATS
- COUPER L'ALIMENTATION AVANT L'ENTRETIEN
- ASSURER QUE LE LUMINAIRE EST MIS A LA TERRE
- SI L'AMPOULE DE CE LUMINAIRE A PROTECTION THERMIQUE CLIGNOTE, CELA PEUT SIGNIFIER UNE SURCHAUFFE
- NE PAS METTRE L'ISOLANT A MOINS DE 3" DE TOUTE PARTIE DU LUMINAIRE
- LES FILS D'ALIMENTATION 90°C MIN POUR EMPLACEMENT SECS SEULEMENT

- ALERTE -** pour réduire le risque D'INCENDIE OU DE BLESSURE:
- coupez l'alimentation électrique et laissez refroidir avant de remplacer l'ampoule
 - la lampe chauffe rapidement!
 - ne touchez pas l'objectif à chaud, la












garde, le réflecteur ou une enceinte
- gardez le luminaire loin de matériaux qui peut brûler
- ne jamais touchez l'ampoule; utilisez un chiffon doux; l'huile de la peau peut endommager l'ampoule
- luminaires équipés avec un verre de sécurité doivent operé d'un verre de sécurité complet et en place












Le luminaire ne peut être utilisé qu' avec des accessoires de Kreon

 = ATTENTION - RISQUE D'INCENDIE - ne pas utiliser une ampoule conçue seulement pour des luminaires fermés

Cette notice de montage ne couvre pas tous les détails ou les variations. Pour des informations supplémentaires veuillez contacter votre représentant local ou un des bureaux Kreon.

1 notifications

<div>technics</div>	<div>In-Line and In-Dolma : Prologe 80</div> <div>     </div> <div> <div>Prologe 145 Single</div> <div>Prologe 145 Double</div> <div>Prologe 145 in-Line</div> <div>Prologe 145 in-Dolma</div> </div>	<table> <tr> <th>Name</th><th>Reference</th><th>L x W x H</th></tr> <tr> <td>Prologe 145 in-Line / in-Dolma Single</td><td>ku(x)98511_, ku(x)98512_, ku98513_, ku98518_, ku98519_</td><td>5 1/2" x 5 1/2" x 4"</td></tr> <tr> <td>Prologe 145 in-Line / in-Dolma Double</td><td>ku(x)98521_, ku(x)98522_, ku98528_</td><td>11" x 5 1/2" x 4"</td></tr> </table>	Name	Reference	L x W x H	Prologe 145 in-Line / in-Dolma Single	ku(x)98511_, ku(x)98512_, ku98513_, ku98518_, ku98519_	5 1/2" x 5 1/2" x 4"	Prologe 145 in-Line / in-Dolma Double	ku(x)98521_, ku(x)98522_, ku98528_	11" x 5 1/2" x 4"
Name	Reference	L x W x H									
Prologe 145 in-Line / in-Dolma Single	ku(x)98511_, ku(x)98512_, ku98513_, ku98518_, ku98519_	5 1/2" x 5 1/2" x 4"									
Prologe 145 in-Line / in-Dolma Double	ku(x)98521_, ku(x)98522_, ku98528_	11" x 5 1/2" x 4"									
<div>2 dimensions</div>	<div>  </div>	<table> <tr> <th>Name</th><th>Reference</th><th>L x W x H</th></tr> <tr> <td>Custom length in-Line Profile</td><td>ku785102, ku785103</td><td>(L+2/5") x 6 6/8" x 9 5/8"</td></tr> <tr> <td>Custom length in-Dolma Profile</td><td>ku785002, ku785003</td><td>(L+2/5") x 6 6/8" x 7 1/2"</td></tr> </table>	Name	Reference	L x W x H	Custom length in-Line Profile	ku785102, ku785103	(L+2/5") x 6 6/8" x 9 5/8"	Custom length in-Dolma Profile	ku785002, ku785003	(L+2/5") x 6 6/8" x 7 1/2"
Name	Reference	L x W x H									
Custom length in-Line Profile	ku785102, ku785103	(L+2/5") x 6 6/8" x 9 5/8"									
Custom length in-Dolma Profile	ku785002, ku785003	(L+2/5") x 6 6/8" x 7 1/2"									
<div>3 installation</div>	<div> <div>hang the profile with the safety brackets to the primary ceiling</div>  </div>	<div>    </div>									
<div>4 installation</div>	<div> <div>choose a knock-out, push out and connect lead cable</div> <div>install plasterboard around the profile</div>  </div>	<div> <div>slide perforated brackets into gap</div> <div>and fix with plasterboard screws</div>  </div>									
<div>5 installation</div>	<div> <div>line out the profile with the plasterboard by turning the black screws in the profile in the correct order</div> </div>	<div> <div>finish with plaster; kreon recommends polyester filler 2K</div> </div>									
<div>kreon nv</div>											

	technics				
6	installation	 <p>mount the gearbracket in profile and make connection</p>	<ul style="list-style-type: none">- connect black supply wire with black wire in profile- connect white supply wire with white wire in profile- connect green earthing wire with green earthing wire in profile <p>connect supply wires with proper size wire nuts after connection replace cover so all wiring and connections are enclosed in profile</p>	 <p>place 2 installation brackets in the profile. keep a distance of +/- length of luminaire between these brackets</p>	
7	installation	 <p>click chassis in profile, between the fastening brackets</p>		 <p>fix chassis to brackets with screws</p>	 <p>click the housing over the chassis</p>
8	connection	<p><u>In case of low voltage lamps</u></p>  <p>connect supply wires to fixtures</p>	<ul style="list-style-type: none">- connect black wire from thermal protector to black supply wire- connect white wire from gear to white supply wire- connect green grounding wire to grounding <p>after connection replace cover so all wiring and connections are enclosed in the junction box</p>	<p><u>In case of line voltage lamps</u></p>  <p>connect supply wires to fixture</p>	<ul style="list-style-type: none">- connect black wire from thermal protector to black supply wire- connect wire from lampholder to white supply wire- connect green grounding wire of luminaire to grounding wire from profile <p>after connection replace cover so all wiring and connections are enclosed in the profile</p>
9	pictures	<p><u>In case of CMH lamps</u></p>  <p>connect supply wires to fixtures</p>	<ul style="list-style-type: none">- connect black wire from thermal protector to black supply wire- connect white wire from gear to white supply wire- connect green grounding wire to grounding <p>after connection replace cover so all wiring and connections are enclosed in the junction box</p>		
	kreon nv	Industrieweg Noord 1152 B 3660 Opglabbeek Belgium	Tel + 32 89 81 97 80 Fax + 32 89 81 97 90	www.kreon.com mailbox@kreon.be	Rev. date :21/04/2009 KR8850001706