

IMPORTANT SAFETY INSTRUCTIONS - SAVE THESE INSTRUCTIONS

Installation instructions for KREON - PROLOGE 80 surface mounted

! WARNING READ AND UNDERSTAND ALL INSTRUCTIONS BEFORE STARTING INSTALLATION. SAVE THESE INSTRUCTIONS FOR FUTURE REFERENCE

! RISK OF FIRE! - RISK OF SHOCK!
- INSTRUCTIONS PERTAINING TO A RISK OF FIRE OR INJURY TO PERSONS
THIS LUMINAIRE MUST BE INSTALLED TO CONFIRM WITH NEC AND ALL LOCAL ELECTRICAL & BUILDING CODES & PRACTICES. TO ASSURE

FULL COMPLIANCE WITH LOCAL CODES AND REGULATIONS, CONSULT WITH YOUR LOCAL ELECTRICAL INSPECTOR BEFORE INSTALLATION.
- DISCONNECT POWERSUPPLY BEFORE INSTALLING OR SERVICING
- ENSURE THE LUMINAIRE IS GROUNDED

- LUMINAIRE IS SURFACE MOUNTED ONLY
- SUITABLE FOR INDOOR DRY LOCATIONS ONLY

WARNING - to reduce the risk of FIRE OR INJURY:
- turn off power and allow to cool before replacing lamp

1 notifications

- lamp gets HOT quickly! contact only switch/plug when turning on
- do not touch hot lens, guard, reflector or enclosure
- keep lamp away from materials that may burn
- do not touch lamp at any time; use soft cloth; oil from skin may damage the lamp
- do not operate the luminaire with a missing or damaged shield, if required

The luminaire can only be used with Kreon accessories.

! CAUTION - RISK OF FIRE - do not install a lamp identified for use only in enclosed luminaires

This installation manual might not cover all details or variations. When additional information is required, please contact your local representative, or one of the Kreon offices.

Notice de montage pour KREON - PROLOGE 80

! ATTENTION: LIRE ET COMPRENDRE TOUTES LES INSTRUCTIONS AVANT L'INSTALLATION CONSERVER CES INSTRUCTIONS POUR DE FUTURES REFERENCES

! RISQUE D'INCENDIE! RISQUE DE CHOC!

- INSTRUCTIONS RELATIVES À UN RISQUE D'INCENDIE OU DE BLESSURE
- CE PRODUIT DOIT ETRE INSTALLE SELON LE CODE D'INSTALLATION PERTINENT, PAR UNE PERSONNE QUI CONNAIT BIEN LE PRODUIT ET SON FONCTIONNEMENT AINSI QUE LES RISQUES INHERENTS
- CONSULTER UN ELECTRICIEN QUALIFIE POUR VOUS ASSURER QUE LES CONDUCTEURS DE LA DERIVATION SONT ADEQUATS

- COUPER L'ALIMENTATION AVANT L'ENTRETIEN
- ASSURER QUE LE LUMINAIRE EST MIS A LA TERRE
- MONTER LE LUMINAIRE EN SURFACE SEULEMENT
- POUR EMBLACEMENT SECS SEULEMENT

ALERTE - pour réduire le risque D'INCENDIE OU DE BLESSURE:
- coupez l'alimentation électrique et laissez refroidir avant de remplacer l'ampoule
- la lampe chauffe rapidement!
- ne touchez pas l'objectif à chaud, la garde, le réflecteur ou une enceinte
- gardez le luminaire loin de matériaux qui peut brûler
- ne jamais touchez l'ampoule; utilisez un chiffon doux; l'huile de la peau peut


endommager l'ampoule
- luminaires équipés avec un verre de sécurité doivent operé d'un verre de sécurité complet et en place

Le luminaire ne peut être utilisé qu' avec des accessoires de Kreon


! ATTENTION - RISQUE D'INCENDIE - ne pas utiliser une ampoule conçue seulement pour des luminaires fermés

Cette notice de montage ne couvre pas tous les détails ou les variations. Pour des informations supplémentaires veuillez contacter votre représentant local ou un des bureaux Kreon.

Prologe 80 Single, Prologe 80 Double



Prologe 80 Single



Prologe 80 Double


2 dimensions

Name	Reference	L x W x H
Prologe 80 Single MR16	ku(x)96811_	3" x 3" x 61/8"
Prologe 80 Single PAR16	ku96813_	3" x 3" x 61/8"
Prologe 80 Single LED	ku96712_	3" x 3" x 61/8"
Prologe 80 Double LED	ku96722_	57/8" x 3" x 61/8"
Prologe 80 Double MR16	ku(x)96821_	57/8" x 3" x 61/8"
Prologe 80 Double PAR16	ku96823_	57/8" x 3" x 61/8"
Prologe 80 Triple D(T4)	ku(x)96834_	87/8" x 3" x 61/8"


technics




install octagonal junction-box size 4
aligned with the wall



screw the supplied plasterkit on the
installed junction-box





plaster the edges of the plasterkit
do not plaster the centerhole nor
the slipholes with the nuts



make connection

3 installation



- connect black wire from transformer/
driver to black supply wire
- connect white wire from transformer/
driver to white supply wire
- connect green grounding wire from
conduit to green grounding wire from
luminaire


Reference	Input Voltage ↴
ku96811_, ku96813_, ku96821_, ku96823_, ku96834_, ku96712_*	120V
kx96811_, kx96821_, kx96834_	277V

4 connection


connect to correct current (see table)

wire scheme


* TRIAC dimmable LED driver inside



in case of Prologe Single:
screw box onto plasterkit and align




in case of a white prologe
assemble the supplied black cover




place housing over springs


5 installation Prologe Single




drill holes on distance x=5", install
plugs and follow steps under connection



screw box on ceiling and place housing
over springs





in case of a white prologe
assemble the supplied black cover



screw box on ceiling and place housing
over springs

6 installation Prologe Double

technics



7 lamp placement

remove the housing

place lamp and replace housing



8 pictures

The luminaire can only be used with Kreon accessories.

This installation manual might not cover all details or variations. When additional information is required, please contact your local representative, or one of the Kreon offices.