






technics		Name Down in-line 120 plasterkit (shadow gap)	Reference KR707214 (8)	Lamptype LED dir, fixed, WW LED dir low	A x B 144x144 144x144	CxD 305x305 400x400	E <sub>min</sub> 200 140	Plasterboard thickness 120 range	9-26
----------	---	---	------------------------------	---	-----------------------------	---------------------------	--------------------------------	----------------------------------	------

## 1 cut out

	Name Down in-line 120 plasterkit no shadow gap Down in-line 120 plasterkit shadow gap	Reference KR707214 KR707218	Visible IxJ 120x120 126x126	H 43 43
--	---	-----------------------------------	-----------------------------------	---------------

## 2 dimensions

	<p>Please make sure that sticker is removed before proceeding!</p>		
3 installation	Put the plasterkit through the hole.	Fix the plasterkit with the screws.	Assembling torque max 20 CN.m.

4 installation	Assembling principle	Fill around perimeter of plasterkit using suitable filler and plaster to hide screws and plasterkit.	Minimum filler distance, spread out until zero.