


# kreon installation manual

## technics & dimensions




recommended orientation

name	reference	Voltage (V)	LxWxH	A	Dim
Onn wall 165	KR98331X	230	201x35x165	114	DD
Onn wall 165	KR98351X	230	201x35x165	114	DD
Onn wall 300	KR98332X	230	201x35x300	249	1-10V
Onn wall 300	KR98352X	230	201x35x300	249	1-10V
Onn wall 165 gen 2	KR98341X-XXXX-XX	230	201x35x165	114	SW, DD or VD
Onn wall 300 gen 2	KR98342X-XXXX-XX	230	201x35x300	219	SW, DD or VD


Please make sure the main voltage is disconnected before proceeding! ⚡

### 1. installation


Remove the two socket set screws with an allen key.



Slide the two allen keys into the holes to open the fixture.




Remove the housing.




### 2. installation


Disconnect the connector.



Supply power from wall and drill two installation holes.




Rotate the mounting plate with LED-driver 90° down.




# kreon installation manual

## 3. installation


Pull power supply cable through hole.



Screw the mounting assembly with the fixation extrusion to the wall.




Remove the plastic cover.




## 4. installation


Connect powersupply and/or dali dim.



Place the plastic cover back and fix it with the screws.




Rotate the mounting plate with LED-driver horizontally.




## 5. installation

Connect the connector.



Close the housing until it clicks over the springs.



Fix the two socket set screws with an allen key.

