



technics

diapason gearbox




for installation on the wall:
provide holes and fix with screws



fix the diapason to the lit

Always make sure
the highest black
ring is mounted
against the
Diapason




cut out for wall installation


Reference	Lampwattage	Dimensions	Cut Out L x W
kr99620x	no gear	190 x 105 x 43	180 x 95
kr99654x	no gear	190 x 105 x 43	180 x 95
kr99664x	no gear	255 x 105 x 43	245 x 95
kr99615x	1 x 20W	170 x 80 x 43	160 x 70
kr99611x-xx	20 - 50W	170 x 80 x 43	160 x 70
kr99616x	1 x 35W	170 x 80 x 43	160 x 70
kr99612x	35 - 105W	170 x 80 x 43	160 x 70
kr99655x	1 x 20W	190 x 105 x 43	180 x 95
kr99621x	35 - 105W	190 x 105 x 43	180 x 95
kr99656x	1 x 35W	190 x 105 x 43	180 x 95
kr99657x	1 x 70W	190 x 105 x 43	180 x 95
kr99666x	2 x 35W	255 x 105 x 43	245 x 95
kr99662x	50 - 150W	255 x 105 x 43	245 x 95
kr99645x	1x 10W	170 x 80 x 43	160 x 70

1 installation

Please make sure that
mains voltage is disconnected
before proceeding!




connect line cables to gear and earth cable
to connector. fix strain relief to jam cable




in case of no gear : connect line cables
and earth cable to connector. fix strain relief to jam cable


2 connection




close the lit and fasten with screws



fix the diapason to the lit and make
connection with the gear
in case of LED-driver kr99635x: connect
red wire with + and black wire with -



place the springs on the housing.
close the lit and fasten with screws



fold the springs inward and place in hole

3 installation



4 pictures

kreon nv

Industrieweg Noord 1152
3660 Opglabbeek
Belgium

Tel + 32 89 81 97 80
Fax + 32 89 81 97 90

www.kreon.com
mailbox@kreon.be

Rev.date: 10/01/2018
KR8965001357