



kreon installation manual

technics & dimensions



name	reference	voltage	freq	LxWxØ
erubo on track phase dim low output	KR92753X-XXXX-XX	230V	50/60Hz	300x150x80
erubo on track phase dim high output	KR92763X-XXXX-XX	230V	50/60Hz	300x150x80
erubo on track 1-10V dim high output	KR92764X-XXXX-XX	230V	50/60Hz	300x150x80
erubo on track dali dim high output	KR92765X-XXXX-XX	230V	50/60Hz	300x150x80


Please make sure the main voltage
is disconnected before proceeding! ⚡

1. installation

NOTE:


luminaire must be place out of arms reach

to be used with Eutrac® 3~track system only
max. 3 circuits 230/240V
disconnect the powersupply while installing or servicing




2. installation


pull luminaire down from the connector
and rotate 90°



choose the correct circuit on the 3~connector
(by rotation or pull down and rotate)



insert Erubo in track and make connection



kreon installation manual


3. installation

pull luminaire and rotate in preferred direction




4. installation

aim spotlight manually
(caution: lamp can be hot!)




5. accessories

remove louvre



place the anti-glare louvre KR762002
in the louvre and place the accessory
back in the head of the fixture



6. picture

