


kreon installation manual

technics & dimensions




name	reference	voltage VDC	frequency	led current	nom. input current driver	max. power
holon 40 directional on track	KR96261x-XXXX-XX-DD	48	0Hz	700mA	1000mA	30W
holon 40 directional on track	KR96261x-XXXX-XX-VD	48	0Hz	700mA	1000mA	30W
holon 40 directional on track	KR96261x-XXXX-XX-SW	48	0Hz	700mA	1000mA	30W

1. light source/gear information

light source containing product


The light source contained in this luminaire shall only be replaced by the manufacturer or his service agent or a similar qualified person.



Energy Efficiency Class and EPREL-information for each specific LED/fixture can be found on the last page of this manual

gear containing product


the gear contained in this luminaire shall only be replaced by the manufacturer or his service agent or a similar qualified person




Please make sure the main voltage is disconnected before proceeding! ⚡

2. installation

Install the Stucchi low voltage track as prescribed and feed it with 48VDC



Click the fixture into the track
The orientation of the fixture is not important except if 1-10V passive dimming is used (see next remark)



Precaution in case of fixtures with 1-10V dimming!

It is recommended to connect the dimming cables before installing the 1-10V fixtures.

It is recommended to use 1-10V active dimming. In case of passive dimming the polarity (and orientation) of the fixtures is important.


If the 1-10V fixtures don't function:

De-mount the fixtures from the track and mount them again one by one. If a fixture causes a malfunction, take it out and rotate the adapter of the fixture 180°.


kreon installation manual

3. installation

Once the holon is installed it can be inclined in any angle up to 90° by pulling the tube




The holon can rotate max. 330°




4. installation


Use a screwdriver to remove the fixture from the track



Turn the slot in the adapter with the screwdriver to unlock the adapter from the track




Pull the module from the track




accessories

in case of accessories check the manual
KR8622102021 delivered with the accessory



KR762000








KR762200

picture



kreon light source information

Fixture reference	LED reference	Energy Efficiency Class	QR-code	EPREL link
KR96261X-8027-FL-XX KR96261X-8027-SP-XX KR96261X-8027-WFL-XX	KR7000103087	N/A		
KR96261X-9027-DL-XX KR96261X-9027-SP-XX KR96261X-9027-WDL-XX	KR7000104041	G		https://eprel.ec.europa.eu/qr/1204149
KR96261X-9027-FL-XX KR96261X-9027-WFL-XX	KR7000104033	F		https://eprel.ec.europa.eu/qr/1207233
KR96261X-9030-DL-XX KR96261X-9030-SP-XX KR96261X-9030-WDL-XX	KR7000104042	G		https://eprel.ec.europa.eu/qr/1207218
KR96261X-9030-FL-XX KR96261X-9030-WFL-XX	KR7000104034	G		https://eprel.ec.europa.eu/qr/1207509