


kreon installation manual

technics & dimensions




name	reference	current
Module 40 LED 200lm downlighter	KR907033-XXX-XXX	700mA
Module 40 LED 200lm WW	KR9XXXXX-XXX-XXX	700mA

The luminaire must not under any circumstances be covered with heat insulating covers or similar materials.
Cables must not touch the luminaire housing.
The connection cable must be routed so that it does not touch the lamp when the luminaire is tilted.


Please make sure the main voltage is disconnected before proceeding! ⚡

installation


To install the plasterkit.
See installation manual KR8170001755 or KR8170001758.



Put the module on the louvre to install the module.





In case of transformer or ballast.



installation

Put the assembly in the plasterkit until the louvre clicks.
See manual KR8170001761, KR8170001762 or KR8000002281.



Downlight

WW

In case of WW

