


kreon installation manual

technics & dimensions




recommended orientation

name	reference	Voltage (V)	LxWxH	A	Dim
Onn wall 165	KR98331X	230	201x35x165	114	DD
Onn wall 165	KR98351X	230	201x35x165	114	DD
Onn wall 300	KR98332X	230	201x35x300	249	1-10V
Onn wall 300	KR98352X	230	201x35x300	249	1-10V


Please make sure the main voltage is disconnected before proceeding! ⚡

1. installation


Remove the two socket set screws with an allen key.



Slide the two allen keys into the holes to open the fixture.




Remove the housing.




2. installation


Disconnect the connector.



Supply power from wall and drill two installation holes.




Rotate the mounting plate with LED-driver 90° down.




kreon installation manual

3. installation


Pull power supply cable through hole.



Screw the mounting assembly with the fixation extrusion to the wall.




Remove the plastic cover.




4. installation


Connect powersupply and/or dali dim.



Place the plastic cover back and fix it with the screws.




Rotate the mounting plate with LED-driver horizontally.




5. installation

Connect the connector.



Close the housing until it clicks over the springs.



Fix the two socket set screws with an allen key.

