

# Kreon

- the fixture is IP67 rated
- the fixture is water- and dust tight
- water should be able to flow of the product once installed
- when installed in solid ground (with or without matchbox) additional drainage must be provided (for example: a bed of gravel)
- make sure the coating (of the housing or other parts) is not damaged during installation or maintenance work: the damage can after contact with water
- the fixture should not be placed in road lanes, it should not be exposed to strain due to braking, acceleration and change of direction
- in order for the product to take pressure load, a proper foundation for the fixture should be provided by the client
- it is recommended to use the fixture in ground with a pH value between 5 and 8
- client should under no circumstances open the fixture themselves, in case of a problem, the fixture needs to be sent back to





result in corrosion

direction

Kreon

up outdoor

up in-line outdoor




name	reference	voltage/current
up outdoor 8,4W LED	KR982101/KR982102	230V
up outdoor 18,5W LED	KR982121/KR982122	26,5V/700mA
up outdoor 18,5W LED, wallwasher	KR982181/KR982182	26,5V/700mA
up in-line outdoor 8,4W LED	KR982301/KR982302	230V
up in-line outdoor 18,5W LED	KR982321/KR982322	26,5V/700mA
up in-line outdoor 18,5W LED, wallwasher	KR982821/KR982822	26,5V/700mA

Please make sure that main voltage is disconnected before proceeding!



name	reference
matchbox square	KR782103
matchbox square for gear incl	KR782104





## 2 dimensions



install the matchbox according to installation manual KR8820001833 (delivered with the matchbox)

## 3 installation with matchbox

in case of up outdoor



installation with matchbox


align the 3 screws in the frame with 3 of the holes + nuts in the matchbox

use the 3 screws to adjust to fix the frame onto the matchbox


KR8820001833

Sheet 1/5



in case of up in-line outdoor



align the 3 screws in the frame with 3 of the holes + nuts in the matchbox




use the 3 screws to adjust the position of the frame, until it is flush with the floor




installation with matchbox

electric connection in case of 8,4W LED

name	reference	voltage
up outdoor 8,4W LED	KR982101/KR982102	230V
up in-line outdoor 8,4W LED	KR982301/KR982302	230V




make the electrical connection by using the KR782105 coupling sleeve (according to manual) or any suitable connection compartment with required protection class (max. dimensions: 25mm x 30mm x 120mm).





the cable gland  must not be opened!

place the coupling sleeve (or connection compartment) in the matchbox, on the opposite side of the cable entrance in the matchbox




installation with matchbox

electric connection in case of 18,5W LED in combination with matchbox KR782104




make the electrical connection with the gear KR772230, make sure to use a watertight connection. (cf. KR782105) Or make the electrical connection inside the IP66 box that is supplied with the gear KR772232, KR772233 (install the gear inside the box according supplied manual), or any suitable gear in a suitable compartment with the required protection class.

the cable gland  must not be opened!



in case of on/off



in case of 1-10V dimmable




in case of dimmable (no touch dim)

name	reference	current
up outdoor 18,5W LED	KR982121/KR982122	700mA
up in-line outdoor 18,5W LED	KR982321/KR982322	700mA
up outdoor 18,5W LED, wallwasher	KR982181/KR982182	700mA
up in-line outdoor 18,5W LED, wallwasher	KR982381/KR982382	700mA


**IMPORTANT** : check polarity of the LED!!  
 + and - at driver side must match  
 + and - at LED side  
 + = red wire  
 - = black wire

installation with matchbox




installation with matchbox

place the IP66 box in the cavity of the matchbox




**NOTE :**  
 in case the gear is placed on remote and is not included in the matchbox, the installation will be similar to the installation explained under electrical connection of 8,4W LED  
 Take into account that in this case the polarity of the LED is important!  
 + and - at driver side must match + and - at LED side  
 + = red wire  
 - = black wire




installation with matchbox


align the two springs on the product with the cut-outs in the frame



install the product by clicking it into the frame




in case of wallwasher




installation with matchbox

in case of wallwasher version, the orientation of the product is important. Always make sure that the lines in the wallwasher lens are parallel to the wall that needs to be enlightened.




dimensions




name	reference	cut-out WxLxH
up outdoor 8,4W LED	KR982101 / KR982102	156mm(+2/-0mm)x156mm(+2/-0mm)x min.97mm
up outdoor 18,5W LED	KR982121 / KR982122	156mm(+2/-0mm)x156mm(+2/-0mm)x min.97mm
up outdoor 18,5 W LED, wallwasher	KR982181 / KR982182	156mm(+2/-0mm)x156mm(+2/-0mm)x min.97mm
up in-line outdoor 8,4W LED	KR982301 / KR982302	156mm(+2/-0mm)x156mm(+2/-0mm)x min.97mm
up in-line outdoor 18,5W LED	KR982321 / KR982322	156mm(+2/-0mm)x156mm(+2/-0mm)x min.97mm
up in-line outdoor 18,5W LED, wallwasher	KR982381 / KR982382	156mm(+2/-0mm)x156mm(+2/-0mm)x min.97mm

5 installation in hollow floor



installation in hollow floor



align the two springs on the product with the cut-outs in the frame




click the frame onto the product



electric connection in case of 8,4W LED

name	reference	voltage
up outdoor 8,4W LED	KR982101/KR982102	230V
up in-line outdoor 8,4W LED	KR982301/KR982302	230V




make the electrical connection by using the KR782105 coupling sleeve (according to manual) or any suitable connection compartment with required protection class

installation in hollow floor

the cable gland  must not be opened!

electric connection in case of 18,5W LED




make the electrical connection with the gear KR77230, make sure to use a watertight connection. (cfr KR782105). Or make the electrical connection inside the IP66 Box that is supplied with the gear KR77232, KR77233 (install the gear inside the box according supplied manual), or any suitable gear in a suitable compartment with the required protection class. the cable gland  must not be opened!

name	reference	current
up outdoor 18,5W LED	KR982121/KR982122	700mA
up in-line outdoor 18,5W LED	KR982321/KR982322	700mA
up outdoor 18,5W LED, wallwasher	KR982181/KR982182	700mA
up in-line outdoor 18,5W LED, wallwasher	KR982381/KR982382	700mA


For the correct connection of the different type of gears, see page 2

installation in hollow floor


in case of up outdoor



install the product in the cut-out in the floor



in case of wallwasher




In case of wallwasher version, the orientation of the product is important. Always make sure that the lines in the wallwasher lens are parallel to the wall that needs to be enlightened.

name	reference
up outdoor 8,4W LED	KR982101/KR982102
up outdoor 18,5W LED	KR982121/KR982122
up outdoor 18,5W LED, wallwasher	KR982181/KR982182


installation in hollow floor

in case of up in-line outdoor




installation in hollow floor

in case the depth is 92mm, install the product in the cut-out of the floor



in case the depth is > 92mm, first fill out the depth until the correct depth of 92mm is reached








in case of wallwasher

name	reference
up in-line outdoor 8,4W LED	KR982301/KR982302
up in-line outdoor 18,5W LED	KR982321/KR982322
up in-line outdoor 18,5W LED, wallwasher	KR982381/KR982382

in case of wallwasher version, the orientation of the product is important. Always make sure that the lines in the wallwasher lens are parallel to the wall that needs to be enlightened.

in case of up (in-line) outdoor installed with matchbox



in case of up (in-line) outdoor installed in hollow floor

removal up outdoor

in order to take the up back out the floor: place the delivered suction cup on the glass and pull the fixture out

when installed in a matchbox: only the product itself without the finishing frame will be pulled out

when installed in a matchbox: the product plus the finishing frame will be pulled out of the cut-out all at once

6 | pictures



Kreon nv

Industrieweg Noord 1152  
B 3660 Opglabbeek  
Belgium

Tel +32 89 81 97 80  
Fax + 32 89 81 97 90

www.kreon.com  
mailbox@kreon.be

KR8820001833  
revision date: 10/07/2013

Sheet 5/5