



kreon installation manual

technics & dimensions



name	reference	$\varnothing A$	B
diapason 80 - ato single anti-glare louvre	KR706070	47	3
diapason 80- ato single diffusing lens	KR706270	47	3
diapason 120 anti glare louvre	KR706080	89	3
diapason 120 diffusing lens	KR706280	89	3
diapason 120 sculpture lens	KR706180	89	3


1. installation



Place lens in glare preventer
Place spring on top of lens
Make sure the spring is fitted in the provided groove

Diffusing and sculpture lenses to be placed with the smooth side facing the LED

Each glare preventer can hold max. 2 lenses



For diapason 80 and ato single use diapason 80 rounded glare preventer KR70673x
diapason 80 straight glare preventer KR70672x

For diapason 120 use diapason 120 rounded glare preventer KR70683x
diapason 120 straight glare preventer KR70682x

To install glare preventer consult installation manual KR8166002147