


# kreon installation manual





## technics & dimensions



Name	Reference
spacer wabi	KR743950

Please make sure the main voltage is disconnected before proceeding! ⚡

## 1. installation




drill mounting holes in the indicated position  
the mounting holes in the spacer are suited for a  $\varnothing 4$ mm screw


fix the spacer with fasteners suitable for  
the surface used

pull the mains supply cable through  
the cut-outs in the spacer

## 2. installation



take the installation part that is delivered with the Wabi fixture itself and mount it with the 3x M5 screws onto the spacer. Pull the cable through the holes of the installation part



for the installation of the Wabi fixture itself, use manual KR8430522152 that is delivered with the fixture (start from page 2)

