



kreon installation manual

technics & dimensions



Name


glare preventor H50 wabi

Reference


KR743052

1. installation


slide the glare preventor in the gap between glass and head of Wabi



make sure to align the screws in the glare preventor with the threads in the head of Wabi



fix the three screws with the included hex key



2. installation

