


kreon installation manual

technics & dimensions




name	reference	LxW	H
Plasterkit 40 recessed suspension	KR791100	36x36	32


Please make sure the main voltage is disconnected before proceeding! ⚡

1. installation dimensions


Minimum height for suspension



KR762700 on/off driver, minimum height of 158mm
KR762902 1-10V driver, minimum height of 140mm




In case of other gear, length gear + 30mm
Make sure gear fits through the opening of the plasterkit (max 35x19mm)




2. installation


First install a plasterkit:
See installation manual KR8170001755 or KR8170001758.



In case of driver on ceiling:
Connect the main supply to the driver and push the driver perpendicular through the plasterkit




Place the driver on the ceiling




kreon installation manual

3. preparation


Place louvre (1) and ceiling cover (2) over the cable in the correct order



Place plasterlock (3) and zip tie (4) over the cable in the correct order, tighten zip tie near the end of the cable.




Tighten cable gland at the desired suspension height using the included tool




4. installation


Connect wiring, mind the polarity; connect red to red (+ positive) and connect black to black (- negative)



Align plasterlock with plasterkit and insert locking mechanism using the tool




click!




5. adjusting pendant height


Un-screw cable gland.



Set desired suspension height.




Tighten cable gland.




kreon installation manual

4. finishing


Align springs of the louvre with the slots in the plasterkit



Insert suspension cover and louvre




Result




5. removing the pendant


Remove louvre and suspension cover



Insert tool in the locking system with the correct way up




Insert hex key in the small hole of the plaster lock



6. removing the pendant

Simultaneously push the hex key up and gently turn the tool counter clockwise



Remove plasterlock from plasterkit

