


kreon installation manual

technics & dimensions



name

Dropped louvre aplis in line 40
Dropped louvre aplis in-line 80

reference

KR707806/KR707802
KR717906/KR717902

BxH


45x35,3
85x46,5

H1


24
24

installation


In case of aplis 80



Push the safety cable through the hole in the plasterkit
Do this before installing the module




Pull the safety cable all the way to the slot
for the safety cable to work correctly




Insert the louvre in the plasterkit after installing the module
Align the springs in the slots

installation

In case of aplis 80
with old plasterkit




Push the safety cable behind a spring in the plasterkit
Push the spring back with a screwdriver if necessary, don't pull!
Do this before installing the module



Insert the louvre in the plasterkit after installing the module
Align the springs in the slots

In case of aplis 40



Insert the louvre and the module in the plasterkit
Align the springs in the slots

pictures

