


technics



Name

Module 120 QT12-ax

Module 120 HIT-TC-CE

Module 120 LED

Reference

KR907813

KR907803

KR907833

Voltage

12V





230V/1,5kV

Drive current

500mA or 700mA

The luminaire must not under any circumstances be covered with heat insulating covers or similar materials.
Cables must not touch the luminaire housing.
The connection cable must be routed so that it does not touch the lamp when the luminaire is tilted.

1 dimensions







2 installation

To install the plasterkit.
See installation manual KR8079332126 or KR8070002005.

Bend the springs to
remove the filterholder.

Insert the reflector in the
movement mechanism.





3 installation

Insert the reflector in the socketholder.
See installation manual KR8200001557.


Optional: add extra filters to
the filterholder.

Maximum capacity= one filters.

In case of QT12 and HIT-TC-CE add lamp.



Please make sure that
main voltage is disconnected
before proceeding!




4 installation

Align A with B and add the filterholder.




Add filterholder.

Install the correct gear with strain relief
on the hollow ceiling.

technics



make sure the female connector is wired the same as the male connector, 1 is + and red, 2 is - and black:





5 installation


In case of LED important: always check the polarity!!
+ = red wire - = black wire

In case of qt12 or HIT-TC-CE connect the supply cable to the connector and use the strain relief.

Put the assembly in the plasterkit.





Push filterholder to rotate inner part manually.



Turn inner part manual.

6 installation



To install the louvre see manual KR8170001761 or KR8170001762.